


7701170
Hanging Parasol

**HOUSE
NORDIC**



FR
Pensez à
donner ou recycler.



Association

ou





Magasin

ou







Déchèterie

<https://quefairedemesdechets.fr>



MONTAGE / MONTAJE / ASSEMBLY / MONTAGEM / MONTAGGIO / MONTAGE

A		x1
B		x1
C		x1
D		x1
G		x1

H		x1
I		x1
K		x1

E



x8

F




x8


J




x1



1




2




E x8 **F** x8


3




4







5



6






Warnings and recommendations




- **Warranty:** Only products used in accordance with the Manufacturer's instructions are subject to warranties and complaints.



- If wind speed exceeds 6 m/sec or in heavy rain conditions, carefully remove the product, fold and secure it and put in a safe place.



- **Recommend to use cover, when parasol not in use.**



-  Please empty the base after use (after season).

- Dry the canvas and the frame, fold it carefully and storage the components in a dry place.